



## WR04026

- Step 1. Remove top deck, air box top and intake ribbon
- Step 2. Increase the existing hole in the back of airbox to 2.5" Fig. 1
- Step 3. Using a 2.5" hole saw, bore a new hole in the front of the airbox. Fig. 2
- Step 4. Install hose coupling onto the throttle body. Fig. 3
- Step 5. Reinstall airbox top. Install tube and clamp through holes in box. Fig. 4
- Step 6. Position filter so it clears the gas inlet tube by 1/8" Fig. 5
- Step 7. Tighten clamps on coupler. Install new vent line from the head fitting to the filter. Fig. 5
- Step 8. Reinstall deck and check the filter position through the inspection cover

