



WORX RACING INTAKE GRATE

PART # - WR204

MODELS: KAWASAKI 440/550

INSTALLATION INSTRUCTIONS

IMPORTANT: READ ALL INSTRUCTIONS BEFORE PROCEEDING WITH INSTALLATION

Parts Supplied:

1 x WORX WR204 Intake Grate
2 x 25mm x 6mm Allen Head Bolts
1 x 12mm x 6mm Allen Head Bolts

- 1- Put ski on a flat surface. Roll onto left side. Remove intake grate, wipe clean any old silicone and residue from hull.
- 2- Apply a small amount of Marine silicone sealant to both mounting surfaces of your new **WORX** Intake Grate.
- 3- Fit **WORX** Intake Grate into position using the Allen Headed bolts supplied:
Important Use the shorter (M6 x12mm) bolt in the rear mounting holes.
Failure to do this could cause damage to pump housing, tighten bolts.
- 4- Wipe off excess sealant with a damp cloth. Allow 24 hours minimum for sealant to cure before riding.
- 5- Regularly check all bolts are tight on your intake grate.

Thank you for purchasing **WORX Racing components** products. We firmly believe that **WORX Racing Components** products are among the finest watercraft parts available. A great deal of time and effort has gone into the design and development of this product to ensure that it will perform to the highest standard and that installation is a relatively straight forward and simple procedure. If you have any questions or comments on the performance and/or installation of our products please contact us at the numbers listed on page one or through your local **WORX** dealer.

www.worx.com.au / info@worx.com.au
