



WORX RACING INTAKE GRATE

PART # - WR215

MODELS: KAWASAKI ULTRA 130/ ULTRA 150

INSTALLATION INSTRUCTIONS

IMPORTANT: READ ALL INSTRUCTIONS BEFORE PROCEEDING WITH INSTALLATION

Parts Supplied: 1 x WORX WR215 Intake Grate

- 1- Remove stock ride plate to access rear intake grate bolts. Remove stock intake grate and clean hull of old silicone and residue.
- 2- Apply Marine silicone sealant around mounting holes on WORX intake grate and around rear mount surfaces and edges of intake grate.
- 3- Fit WORX intake grate into position using OEM bolts. You will have to remove washers from front bolts. Refit ride plate.
- 4- Wipe away excess sealant with cloth. Allow 24 hours for sealant to cure before riding
- 5- Regularly check that all bolts are tight on your intake grate and ride plate.

Thank you for purchasing **WORX Racing Components** products. We firmly believe that **WORX Racing Components** products are among the finest watercraft parts available. A great deal of time and effort has gone into the design and development of this product to ensure that it will perform to the highest standard and that installation is a relatively straight forward and simple procedure. If you have any questions or comments on the performance and/or installation of our products please contact us at the numbers listed on page one or through your local **WORX** dealer.

www.worx.com.au / info@worx.com.au