



WORX RACING SPONSONS KIT

PART # - WR548-JB

MODELS: SEADOO RXPX 12+

INSTALLATION INSTRUCTIONS

IMPORTANT: READ ALL INSTRUCTIONS BEFORE PROCEEDING WITH INSTALLATION

Parts Supplied: 2 x **WORX Racing** adjustable sponson paddles
 2 x **WORX Racing** Block off
 10 x M8 x 30mm Button head bolts

- 1- Remove OEM stock sponsons Paddles Using a T40 Torx key remove the 5 x M8 bolts from each sponson paddle. Clear all excess silicone away from behind the OEM sponsons.
Fit the new WORX Racing sponson paddles using the M8 x 30 Button head bolts supplied (start all of the bolts into the side rails before tightening). Fit Front block off pieces to both sides with remaining bolts.
- 2- Adjust the blades according to your riding style: These paddles are adjustable in height, most riders will prefer the setting in the down position for the most aggressive performance.
- 3- After riding for about 15 minutes check that your sponson bolts are tight and when you have decided which position best suits your riding style apply a layer of Marine silicone sealant between the side rails and the sponsons and also apply red loctite to the mounting bolts. **Regularly check that the sponson fixing bolts are tight. The first hour is crucial.**
- 4- **Warning:** These sponsons will vastly improve the turning capability of your boat take time to get used to them before you attempt any hard cornering

Thank you for purchasing **Worx Racing components** products. We firmly believe that **Worx Racing Components** products are among the finest watercraft parts available. A great deal of time and effort has gone into the design and development of this product to ensure that it will perform to the highest standard and that installation is a relatively straight forward and simple procedure. If you have any questions or comments on the performance and/or installation of our products please contact us at the numbers listed on page one or through your local **Worx** dealer.