



## WORX RACING SPONSONS

**PART # - WR563-I**

**MODELS: YAMAHA FX, FX SVHO 2019+**

## **INSTALLATION INSTRUCTIONS**

**IMPORTANT: READ ALL INSTRUCTIONS BEFORE PROCEEDING WITH INSTALLATION**

**Parts Supplied:**

2 x **WORX** adjustable sponspons paddles  
2 x **WORX** Side rails  
2 x **WORX** Side rails  
12 x M8 x 30mm Button Head Bolts  
12 x M8 x 40mm Button Head Bolts  
10 x M8 x 40mm Hex Head Bolts  
10 x 8mm x 19mm Flat Washers

- 1- Remove stock sponspons: Using the 12mm Socket Wrench remove the 5 x OEM bolts from each sponson, clear all excess silicone from behind the OEM sponspons.
- 2- Apply a bead of Marine silicone sealant around the edges of the side rails, and around each of the mounting holes (five on each side).
- 3- Fit the side rails to both sides of the ski using the supplied (M8 x 40) bolts and the 8mm x 19mm flat washers. Tighten using the 13mm the socket wrench. **WORX** Racing's WR563 sponson allows the backing rail to be adjusted according to your riding style. Stock setting is the lower set of mounting holes. To increase stability and help eliminate chine walking, use the top mounting holes of the backing rails.
- 4- Fit the sponspons paddles using the remaining M8 x 40 Button bolts supplied (start all the bolts into the side rail before tightening). Fit spacer between paddle and backing rail.
- 5- Adjust the blades according to your riding style: These paddles are adjustable in height; most riders will prefer the setting in the down position for the most aggressive performance.
- 6- After riding for about 15 minutes check that your sponson bolts are tight and when you have decided which position best suits your riding style it is **RECCOMENDED** that you apply a layer of Marine silicone sealant between the side rails and the sponspons and also apply red loctite to the mounting bolts. **Regularly check that the sponson fixing bolts are tight. The first hour is crucial.**
- 7- **Warning:** These sponspons will vastly improve the turning capability of your boat! Take time to get used to them before you attempt any hard cornering.

Note: Use the M8 x 30mm Button Head Bolts when **NOT** using spacer that is provided.

Thank you for purchasing **WORX Racing Components** products. We firmly believe that **WORX Racing Components** products are among the finest watercraft parts available. A great deal of time and effort has gone into the design and development of this product to ensure that it will perform to the highest standard and that installation is a relatively straight forward and simple procedure. If you have any questions or comments on the performance and/or installation of our products please contact us at the numbers listed on page one or through your local **WORX** dealer.